



Scratch Away®

SAW195 Renovation manual

DB-Imagineering BV
CE Laarakkerweg 10
NL-5061 JR Oisterwijk

info@scratchaway.net

Necessities



Scratch Away SAW195 Polisher



RESTART polish with polishing disc Blue



RECHARGE polish with polishing disc Yellow



Roadmap



STEP 1

Thoroughly clean the frame and surroundings



STEP 2

Polishing agent RESTART on
polishing disc Blue



SAW195 machine in position 1
and then gradually increase the speed
during the process



Machine straight on frame, light pressure



Make S turns while polishing



If necessary, add polish to polishing disc



Also polish the edges of the frame



STEP 2

Polishing compound RECHARGE
on polishing disc yellow



Machine straight on the frame, slight pressure



Also the edge of the frame



STEP 4

Rub with a clean, dry cloth

After a surface has been completely renovated. We advise to maintain the surface every 2 years after proper cleaning, with the yellow RECHARGE polish. In order to provide protection for the coming period to come.



Attention, danger!



Use ear and eye protection during work!



Read the manual and instructions!



Use hand protection during work!

PAY ATTENTION! Read all safety warnings and all instructions.

Failure to follow the warnings and instructions could result in electric shock, fire, or serious injury.

Save all warnings and instructions for future reference.

The term “power tool” used in the warnings refers to power tools for use on the mains (with mains cord) and power tools for use with a battery (without mains cable).